

POLYGRAB

POLYSTYRENE SPRAY ADHESIVE

“A Revolution In The Industry”

Features

- ✓ Ease Of Application
- ✓ Fast Bond Time
- ✓ Long Open Time
- ✓ High Bond Strength
- ✓ Completely Portable
- ✓ Maintenance Free

Application

All surfaces to be bonded should be dry, clean, dust and grease free. To apply Polygrab hold the gun parallel to the work surface and administer a generous coat of adhesive, coverage of at least 80 to 100% is recommended.

Before bringing the two substrates together ensure that the adhesive is allowed to tack up, i.e. to be able to touch without any transference to the fingers. You can now bring the surfaces together using uniform pressure and the workpiece can be instantly handled.

It is important to test all the substrates to be bonded before going into production or undertaking a large contract. It is the responsibility of the user to ensure the adhesive's suitability to the substrates. If you are unsure, please do not hesitate to contact Gemini Adhesives technical department who will be more than happy to assist.

Technical Data

Chemical Name	Sprayable Contact Adhesive
Appearance	Blue Liquid
Coverage	15 sqm Per Kg
Glue	25-29 %
Shear Adhesion	85psi
Shelf Life	1 Year Unopened
C.F.C Free	



Gemini II
II Adhesives

Gemini Adhesives Limited

New Building, Top Road, Osgathorpe, Loughborough, Leics, LE12 9TB. Telephone: 01530 224712 Fax: 01530 223514

www.geminiadhesives.com